

BADER WALL LAMP

INSTALLATION GUIDE



BADER WALL LAMP

NOTICE:



This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect the item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

BEFORE YOU BEGIN

- Have the wall lamp installed by a qualified electrician, following local electrician codes.
- Switch off power at the breaker before starting, and use a voltage tester to confirm there is no live current.
- Make sure the ceiling structure or junction box can support at least twice the chandelier's total weight.
- Check the LED driver for dimmer compatibility before installation

1. Pre-Test the Light

- Connect the fixture temporarily power to check LEDs.
- Disconnect after confirming operation.





2. Remove Mounting Bracket

- Loosen side screws to detach bracket from lamp body.
- Keep screws for re-installation.

3. Fix Bracket to Wall

- Use a stud finder to locate a solid fixing point.
- If mounting to drywall, use rated anchors.
- Position bracket level using alignment template, drill holes, and fix with screws.





4. Connect Wires



- Connect ground (green/yellow) to building ground.
- Connect hot (black/brown) to supply hot, neutral (white/blue) to supply neutral.
- For dimming, connect control leads; cap unused leads.

5. Attach Lamp Body

- Hook lamp body onto the bracket from the top.
- Pivot down into place, ensuring wires are tucked without pinching.
- Secure using screws on all sides.

6. Align and Secure Front Disc

- Wear gloves; align moon graphics upright (match product photos).
- Tighten rim/set screws evenly.



7. Final Cleaning & Check

- Remove protective film.
- Wipe with microfiber cloth.
- Check fixture is level and secure.

8. Power On Test

- Restore power at the breaker.
- Turn on to confirm smooth performance.



WARRANTY INFORMATION

Damages or Issues:

- Start a return/exchange online and mark the item as damaged
- After 30 days, coverage applies only with an extended warranty
- Submit photos/videos — we'll assess and offer a replacement

Standard Warranty

All fixtures are covered for manufacturer defects for 30 days.
Contact us with proof for a free replacement.

Extended Warranty

Available for 12, 36, or 60 months. Includes:

- Free instant replacements
- Accident & manufacturer protection
- Component coverage (excludes bulbs)

Contacts



Shop Online at
www.residencesupply.com



Follow our Instagram
[@residencesupply](https://www.instagram.com/residencesupply)



24/7 Customer Service
+1 (800)-791-7436

RESIDENCE
SUPPLY